

Heizung speichere aktuelle Temperatureinstellung

Ich war bislang auf dem Weg die Komfort Temperatur über den input_number Helfer fix einzustellen.

Das Leben mit meiner Frau zeigt mir aber, dass es besser ist, die Komfort Temperatur vom Thermostat zu übernehmen.

Ich speichere also die Temperatur vom Thermostat in den input Helfer, solange sie über der ECO Temperatur ist.

```
alias: Heizung speichere aktuelle Temperatureinstellung
```

```
description: ""
```

```
trigger:
```

```
- platform: state
```

```
entity_id:
```

- climate.thermostat_buero
- climate.thermostat_carrera
- climate.thermostat_ez
- climate.thermostat_flur
- climate.thermostat_gruen
- climate.thermostat_kinderbad
- climate.thermostat_lydi
- climate.thermostat_rosa
- climate.thermostat_studio
- climate.thermostat_sz
- climate.thermostat_wc
- climate.thermostat_wcdg
- climate.thermostat_werkstatt
- climate.thermostat_wz

```
attribute: temperature
```

```
condition: []
```

```
action:
```

```
- variables:
```

```
room: "{{ trigger.entity_id.split('_')[1] }}"
```

```
device: "{{ 'climate.thermostat_' + room }}"
eco: "{{ 'input_number.thermostat_' + room + '_eco' }}"
comfort: "{{ 'input_number.thermostat_' + room + '_comfort' }}"
device_temp: "{{ state_attr( device, 'temperature') }}"
eco_temp: "{{ states(eco) }}"
store_temp: "{{ device_temp > eco_temp }}"

- if:
  - condition: template
    value_template: "{{ store_temp }}"
  then:
    - service: input_number.set_value
      data_template:
        value: "{{ state_attr( device, 'temperature') }}"
      target:
        entity_id: "{{ comfort }}"
mode: single
```

Revision #1

Created 10 January 2024 18:07:42 by Gerald Amrhein

Updated 10 January 2024 18:10:03 by Gerald Amrhein